

# Technical Bulletin

# **MAYTAG**<sup>®</sup>

**Date:** June 2006

**Type** Policy Letter  
√ Service Information

**No:** TDL-0127-B  
Page 1 of 1

**Attention** √ Service Managers  
Service and Parts Managers

**Models** MAV4057AWA, MAV4057AWQ, MAV4057AWW, MAV4500AWW, MAV5000AWQ, MAV5000AWW, MAV5057AWQ, MAV5057AWW, MAV5736AWW, MAV5842AWW, MAV6000AWQ, MAV6000AWW, MAV6057AWQ, MAV6057AWW, MAV6200AWQ, MAV6200AWW, MAV6257AWQ, MAV6257AWW, MAV6300AWQ, MAV6300AWW, MAV6357AWW, MAV6451AWQ, MAV6451AWW, MAV6548AWQ, MAV6548AWW, MAV6601AWQ, MAV6601AWW, MAV7000AWQ, MAV7000AWW, MAV7057AWQ, MAV7057AWW, MAV7200AWQ, MAV7200AWW, MAV7346AWW, MAV7357AWQ, MAV7357AWW, MAV7358AWQ, MAV7358AWW, MAV7450AWQ, MAV7450AWW, MAV7501AWW, MAV7504EWW, MAV7551AWQ, MAV7551AWW, MAV7600AWQ, MAV7600AWW, MAV7636AWQ, MAV7636AWW, MAV7642AWQ, MAV7642AWW, MAV7700AWQ, MAV7700AWW, MAV7751AWQ, MAV7751AWW, MAV7757AWQ, MAV7757AWW, MAV7901AWQ, MAV7901AWW, MAV8000AWQ, MAV8000AWW, MAV8057AWQ, MAV8057AWW, MAV8260AWQ, MAV8260AWW, MAV8500AWA, MAV8500AWQ, MAV8500AWW, MAV8600AWQ, MAV8600AWW, MAV8751AWQ, MAV8751AWW, MAV8757AWQ, MAV8757AWW, MAV9501AWQ, MAV9501AWW, MAV9600AWQ, MAV9600AWW, MAV9600EWW, MAV9750AGW, MAV9750AWQ, MAV9750AWW

**Brand**  
Maytag

**Product**  
Laundry

**Issue** Intermittent contact in lid switch causing "Stops Mid-cycle", "Not Spinning", "Wet Clothes", "Poor Draining" complaints.

**Warranty** Standard product manufacturing warranty applies.

**Action** There may be an intermittent contact inside the lid switch. When the contacts open, this indicates to the machine that the lid is open and the washer turns 'OFF'. When checked, the switch appears to operate normally and ohms out correctly.

To identify this condition, turn 'ON' the washer and set into agitation or spin. While washer is running, wiggle the wire harness and connector attached to the lid switch. If the contacts are "bad", the washer will shut 'OFF'. If the washer shuts 'OFF', replace the lid switch.